


CIRCUIT DRAWN WITH
POWER SUPPLY OFF



FOR TYPICAL REMOTE CONTROL
DETAILS SEE DOCUMENT
No RWS

TRANSFORMER TAPPING OPTIONS

TYPE 1

TAP	NOM 50/60HZ	50HZ	60HZ
W	220/230	176-242	198-259
X	380/400	304-418	342-446
Y	415/420	332-457	374-487
Z	440/460	352-484	396-517

FUSE FS1 - 250mA ANTI-SURGE

TYPE 2

TAP	NOM 50/60HZ	50HZ	60HZ
W	346/380	285-388	321-419
X	480/500	406-552	432-564
Y	240/240	192-261	216-282
Z	550/575	445-605	501-654

FUSE FS1 - 250mA ANTI-SURGE

TYPE 3

TAP	NOM 50/60HZ	50HZ	60HZ
X	660/660-690	534-726	600-726
Y	690/---	558-759	

FUSE FS1 - 150mA ANTI-SURGE

ALL TRANSFORMER TYPES - PS1 SELF
RESETTING FUSE.

NOTE
REFER TO PUBLICATION E170E FOR
APPROVED FUSES FS1 AND FS2.
MAX EXTERNAL LOAD ON TERMINALS
4 & 5 TO BE 5W.

CONTROL SIGNAL THRESHOLD VOLTAGES
TO BE MINIMUM 'ON' 20V AC/DC
MAXIMUM 'OFF' = 3V
MINIMUM CONTROL SIGNAL DURATION
TO BE 300mS.

CURRENT DRAWN FROM EACH REMOTE
CONTROL SIGNAL IS 5mA ON 24V DC
OR 12mA ON 120V AC

INDICATION CONTACTS S1-S4 ARE SHOWN
IN THEIR DEFAULT CONFIGURATION.
CONTACTS MAY BE CONFIGURED FOR ANY
OF THE FUNCTIONS DESCRIBED IN E170E

PROFIBUS WILL FUNCTION NORMALLY
WHEN 3-PH MAINS POWER OR EXTERNAL
17-36VDC SUPPLY IS APPLIED.

FOR TYPICAL REMOTE CONTROL
INDICATING, MONITORING AND ALARM
CIRCUITS SEE PUBLICATION E120E

VOLTAGE INPUT (0-5 VOLTS)
+ve TO 'A', 0 VOLTS TO COMMON
CURRENT INPUT (0-20mA)
LINK A TO B, CURRENT SOURCE
BETWEEN A/B AND COMMON.

ANALOGUE I/P 'A'
ANALOGUE I/P 'B'
COMMON

TERMINATOR
PROFIBUS B(IN)
PROFIBUS B(OUT)
PROFIBUS A(IN)
PROFIBUS A(OUT)
SCREEN

No	DATE	REVISION DETAILS
04	200910 PJW	AUX POWER NOTE CHANGED CHECKED JC1

www.rotork.com

ROTORK CONTROLS LTD BATH, BA1 3JQ ENGLAND Tel: 01225-733200	ROTORK CONTROLS INC ROCHESTER NY 14624, USA Tel: 585-247-2304
--	--

CONFIG BY PJW
DATE 300904
CHECKED DA
BASE WD 3050-900
JOB No -
M.I.No -

**IQ + AUX POWER &
SINGLE CHANNEL PROFIBUS**

CIRCUIT DIAGRAM No -REV 102
3050-900-04

B1 C1 B2 C2