


SPARE PARTS LIST FOR RANGE OF IR3 INPUT REDUCERS



EXPLODED VIEW FOR IR3 INPUT REDUCER

ITEM	DESCRIPTION	QUANTITY
1	CIRCLIP	1
*2	BALL BEARING	1
*3	BALL BEARING	1
*4	BALL BEARING	2
*5	BALL BEARING	1
6	END PLATE	1
7	GEARCASE	1
8	GEAR SHAFT	1
9	INPUT FLANGE	1
10	INPUT SHAFT	1
11	KEY	1
12	KEY	1
*13	O-RING	1
*14	O-RING	1
15	OUTPUT GEAR	1
16	OUTPUT GEAR	1
17	SCREW	8
18	SCREW	4
19	SCREW	8
20	SPACER	1
21	SPACER	1
22	GREASE	

Note: items marked * are the recommended spares holding for 5 years operation