


SPARE PARTS LIST FOR MTW3 RANGE OF WORM GEAR ACTUATORS



EXPLODED VIEW FOR MTW3 GEARBOX OPERATIONS

ITEM	DESCRIPTION	QUANTITY
*1	ANGULAR CONTACT BALL BEARING	2
2	BASEPLATE	1
3	ENDCAP	1
4	SCREW	4
5	GEARCASE	1
6	SCREW	8
7	SCREW	4
8	INDICATOR PLATE	1
9	KEY	1
10	LABEL	1
11	INPUT FLANGE	1
12	NAMEPLATE	1
*13	O RING	1
*14	O RING	1
*15	O RING	2
*16	O RING	1
*17	O RING	1
18	OUTPUT SLEEVE	1
19	RIVET (STAINLESS NAMEPLATE ONLY)	2
20	WORM SHAFT	1
21	WORMWHEEL	1
22	GREASE	
23	SHIMS	

Note: Items marked * are the recommended spares holding for 5 years operation

Special solid worm wheels do not have output sleeves and screws but do have the same gearbox rating